




WARNING: Any furniture that is not anchored to a wall has the potential to tip over in certain circumstances, i.e. if a child attempts to climb up on the furniture or in the event of an earthquake. Accordingly, we recommend that all furniture is anchored to a wall.

ASSEMBLY INSTRUCTION

FZ0010011




! Scanning the QR code to open assembly instructions.




ASSEMBLY INSTRUCTION

FZ0010011

Step 1

 a x16PCS



Step 2

