ASSEMBLY INSTRUCTION


FZ0030050


V. 240328.03





| +1(spare) | +1(spare) | +1(spare) 6x30mm | +1(spare) 4x14mm |
|----------------|-----------|---------------------|----------------------|
| Ax43pcs | Bx43pcs | Cx56pcs | Dx24pcs |
| | 4x16mm | | (4) 1 (spare) 4x30mm |
| Ex4pcs | Fx2pcs | Gx2pcs | Hx10pcs |
| #1(spare) | | +1(spare) | (4x35mm) +1(spare) |
| Ix16pcs | Jx1pc | Kx24pcs | Lx8pcs |
| | | 3 x12mm | |
| Maria helideph | Mx2pcs | Nx8pcs | Ox4pcs |


Scanning the QR code to open assembly instructions.
















































Adjustment Diagram for Hinge


Installation Notes:

To prevent issues such as uneven gaps during door installation, we have provided detailed instructions for adjusting the hinges below.




General Instructions:

- To adjust the door position, you will need to loosen or tighten the screws on the hinge.
- It's important to adjust the screws in the elliptical hole positions as shown in the adjustment diagram.
- Ensure to adjust all hinges as described for uniformity.




Adjustment Instructions:

Step 2




1. Raising the Door:

- Loosen the screw on the hinge in a counterclockwise direction at position P1.
- Lift the door to the desired height.
- Tighten the screw clockwise to secure the door in place.




2. Lowering the Door:

- Loosen the screw counterclockwise at position P2.
- Lower the door to the correct position.
- Tighten the screw clockwise to secure.




3. Moving the Door Closer to the Cabinet Frame:

- To move the door closer, loosen the screw counterclockwise at position P3.
- Pull the door outward to adjust, then tighten the screw clockwise.




4. Pushing the Door Away from the Cabinet Frame:

- Loosen the screw counterclockwise at position P4 for adjustment.
- Push the door inward to the correct position, then tighten the screw clockwise.



5. Reducing the Gap Between the Door and Side Panel:

• Rotate the screw counterclockwise at position P5 for adjustment.



6. Increasing the Gap Between the Door and Side Panel:

• Rotate the screw counterclockwise at position P6 to adjust.

Final Step

• After making the necessary adjustments, tighten the screws of all hinges clockwise to complete the installation of the door.

Adjustment Diagram for Hinge:

• Please refer to the adjustment diagram from P1 to P6 for a visual guide on how to make these adjustments.

