

Product name

FZ0070050 V.211129.01

Daisy Desk

USER MANUAL

Thank you for choosing our product. We hope you will find the instructions on this user manual clear and easy to follow. If you take a few minutes to look through it, you'll learn how to assemble and use of your new unit for maximum enjoyment.

This User Manual will provide basic instructions and safety guide for this products. After you have finished reading the instructions, please keep this manual in a safe place for future reference.

Should you ever experience a problem with of any our products, please fell free to contact us.



FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATING INSTRUCTION AND WARNING REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS INJURY.

The safety of our clients and users is our primary concern. To enssure safe operation, please read this instruction carefully.

WARNING: Any furniture that is not anchored to a wall has the potential to tip over in certain circumstances, i.e. if a child attempts to climb up on the furniture or in the event of an earthquake. Accordingly, we strongly recommend securing all furniture to a wall using the anti-topple wall bracket supplied.

We have provided the fittings for attaching the wall bracket to the unit, but due to the different types of walls you might have, we not provided the fitting for attaching the bracket to your wall. You should first identify the type of wall you intent to fix the product to and then contact your local hardware store to get the appropriate fixings.


When attaching to walls always consider the position of any electrical cables or water pipes nearby.



WARNING


FAILURE TO FOLLOW THESE BASIC STEPS CAN LEAD TO DAMAGE THAT IS NOT COVERED BY YOUR WARRANTY

1




Read Instructions carefully. Check no parts are missing.

2




Lay out all of the components on a soft surface as if you were preparing to do a jigsaw puzzle.

3




Carefully identify each component, especially those that are similar. The most common mistake is getting things back to front.

4




Separate and identify each component from the hardware pack and rest each one in its proper location before fastening.

5



DO NOT fully tighten screws leave slightly loose). When the item is fully assembled tighten the screws - but do not over tighten.

6



If glue is required DO NOT set until you are certain that the parts belong together.



Safety and Care Advice

Important – Please read these instruction fully before starting assembly

Check you have all the components and tools listed are included.

Remove all fittings from plastic bags and separate them into their groups.

Keep children and animals away from the work area, small parts could choke it swallowed.

Make sure you have enough space to layout the parts before starting.

Do not stand or put weight on the products, this could cause damaged.

Assemble the item as close to its final position (in same room) as possible.

Do not place furniture direct in front of radiators, fires or any other source of heat.



Parts of assembly will be easier with 2 people.

Assemble on soft level surface to avoid damaging the unir or your floor.



We do not recommend The use of power drill/ drivers for inserting

screws, as this could damage the unit.

Dispose of all packing carefully and responsibly.

General Care And Maintenance

To ensure that you receive maximum pleasure from your new furniture, it is very important foryou to care your products.

Maintain the furniture on a regular basis and in accordance with the instructions

Take care to prevent sharp object and avoid contact with chemicals e.g. cosmetics or hair products which may permanently mark the surface,

From time to time check that all the fitting are tlight on this piece of furniture. Always use coasters to protect surface from moisture and heat.

Take care when moving furnituredragging pieces across the floor will damage the joints.

Avoid exposing your furniture to direct and prolonged periods of sunlight and heat sources as fading and cracking may occur.

Cleaning And Care Of Products

Dust regularly with a clean dry cloth.

Wipe up any spills immediately with a damp cloth and then dry the surface with a clean dry duster.

Remove stubborn stains with weak washing up liquid solution and a damp cloth and dry with a clean dusters.

Do NOT use abrasive cleaners.

Do NOT clean with the following or products containing the following:

Acetone(eg nail vanish remover), Ammonia(eg bleach) or Sodium hydroxide(eg Caustic soda, drain and oven cleaners). In the events of accidental contact rinse thoroughly with water

General Information

If for any reason you should have problems with your products, Please retain your receipt as proof of purchase and contact the store from which you purchased it.



A Guide to - Wall Mounting & Fixings

Important Notes:

Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Wall Fixings:



- because of the variety of different wall types, we have provided kind but may not exact fixings you will need to fix this product to the wall.

In this case, you must first identify the type of wall you intend to fix product onto and then contact your local hardware store to get the appropriate fixings. Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: **General rule:** Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your wall are mad of brick, breeze block, concrete, stones or wood.

No.1 'General Purpose' wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 'Cavity Fixing' wall plug




For use with plasterboard partitions or hollow wooden doors.

No.3 'Hammerfixing wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the

No.4 'Plasterboard' wall plug




For use when attaching light loads on to plasterboard partitions.

No.5 'Cavity Fixing-Heavy Duty' wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 'Shield Anchor' wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.



Ok, let's get rolling

This should be easy, just follow our simple instructions and you will be back to Netflix in no time.

Estimated time for assembly



60:00

What you need

- Some of your favourite bubbly or your preferred relaxant
- Use the packaging carton as a working surface to prevent product damage during assembly

Weight Limitation



66 lbs


What's included

Code	Description	Qty
А	Table top	1
В	Middle support panel	1
С	Right side panel	1
D	Back panel	1
Е	Bottom deck panel	1
F	Top panel	1
G	Left side panel	1
Н	Particle panel	1
I	Cross bar	1
J	Bottom panel	1
К	Door panel	1
L	Left back panel	1

What's included

Code	Description	Qty	Code	Description	Qty
М	Left leg	2	Т	Big drawer bottom	1
N	Right leg	2	U	Big drawer front	1
0	Support crossbar	1	V	Small drawer back	2
Р	Big drawer back	1	W	Small drawer right side panel	2
Q	Big drawer right side panel	1	X	Small drawer left side panel	2
R	Big drawer left side panel	1	Υ	Small drawer bottom	2
S	Drawer support panel	1	Z	Small drawer front	2

The goods




IMPORTANT:

- 1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
- 2. Do not over tighten screws and bolts to avoid stripping.
- 3. Please use hand tools to assemble this product. Do not use power tools.


What's included

Code	Description	Qty	Code	Description	Qty
1	M5X35 MM cam bolt	23	12	Left side panel slide	3
2	Cam lock	23	13	Left side drawer slide	3
3	M6*30 MM wooden dowel	28	14	Right side panel slide	3
4	M4*35 MM screw	43	15	Right side drawer slide	3
5	M4*18 MM screw	8	16	Metal hinge	2
6	3.5*12 MM screw	36	17	M4*12 MM screw	2
7	M4*16 MM bolt	4	18	Wall anchor	2
8	Handle	4	19	Magnetic piece	1
9	Eva pad	4	20	Iron	1
10	Hinger	2	21	M3*14 MM screw	3
11	M4*14 MM screw	8			


The goods




Lay down packaging or carpet as a working surface and let's fire this thing up!




Secure the left side panel slide (12) to the middle support panel (B) and the right side panel slide (14) to the right side panel (C).




Secure the right side panel to the table top.




Attach the middle support panel to the table top.






Screw in the back panel on the top and the sides.




Tip from a friend to a friend: be extra aware of screwing in the side panels correctly. Make note of which way the front and the back goes.




Step 6 cont.


Repeat on the particle panel and don't forget to screw on the magnetic piece!




We know, there are a lot of pieces with this product, but take it slow, you're doing great!




Attach the top panel.




Screw in the back panel. You're halfway there!




Time to secure the back panel and bottom deck panel.






Screw on the hinges to the door panel and twist on the handle.



Is your cabinet door looking crooked or unevenly spaced?


Then you've come to the right place. Follow the illustrations below to get your cabinet door aligned and ready for action.

If your door is too low or too high...




Loosen the height screws, then move the door up or down to make it level.

If the space between your doors is off...




Loosen the side-to-side screws, then screw counter-clockwise to make the gap wider or clockwise to close any gaps.

If you need to adjust the depth of the doors...




Adjust the in-and-out screws until the door is aligned with the side of the cabinet.



Let's consider this your workout for the day. Take a five minute break and order yourself some pizza before coming back to finish up the last drawer. 2 T (T) Pay careful attention to make sure you line the slide drawers up the **7**6 correct way. **6** 6 6 6

Slide in your drawers and ta-da! You did it! *Cue party music*



For safety, we recommend securing your vanity to a wall.