


ASSEMBLY INSTRUCTION

FZ0080060 V.250429.01



! Scanning the QR code to open assembly instructions.




SAFETY INSTRUCTION





WARNING



Children have died from furniture tipover.

- (a) always secure this furniture with an anchor device;
- (b) never allow children to stand, climb or hang on drawers, doors, or shelves;
- (c) never open more than one drawer at a time;
- (d) place heavy items down low;
- (e) never place a television on this furniture.




A  x34	B  x38	C  x27	D M4x40  x20	E M3.5x12  x32	F  x4	G  x3
H M4x20  x3	I  x2	J  x1	K  x1	L M4x10  x4	M  x1	N  x4
O  x2	P  x10	Q  x4	R  x4	S  x1	T  x1	U  x2

Step 1




A x18	E x12
P x6	F x4

Step 2




M	C	B
		
x1	x7	x8

Step 3





C	B
	
x1	x10

Step 4




Step 5




A  x2	C  x2	B  x2
---	---	--

Step 6






C  x6	D  x7
---	--

Step 7





C  x3	D  x3
---	--


Step 8



Step 9





Step 10



C







x2

Step 11






I	E	D
		
x2	x4	x2


Step 12



Step 13




Step 14




A  x4	B  x4	D  x4	G  x1	H  x1
---	---	---	---	--

Step 15




A  x4	B  x4	D  x4	G  x1	H  x1
---	---	---	---	--

Step 16



E	O	G	H
			
x4	x2	x1	x1



Step 17



L


x4

Step 18



E  x12	J  x1	T  x1
--	---	--

Step 19



B  x4	P  x4	Q  x4	R  x4	S  x1
---	---	---	---	--