


WARNING: Any furniture that is not anchored to a wall has the potential to tip over in certain circumstances, i.e. if a child attempts to climb up on the furniture or in the event of an earthquake. Accordingly, we recommend that all furniture is anchored to a wall.

ASSEMBLY INSTRUCTION

FZ0090035

V. 220327. 01











a	x12	b	x14	c	x12	d	x18	e	x4	f	x4	g	x2
h	x2	i	x1	j	x2	k	x4	l	x4	m	x2	n	x4
o	x28	p	x1	q	x4	r	x2						








Scanning the QR code to open assembly instructions.

A	x1	B	x1	C	x1	D	x1	E	x1
F	x1	G	x1	H	x1	I	x1	J	x1
K	x1	L	x1	M	x1	N	x1	O	x1
P	x1	Q	x1	R	x1				


<1>

	a x 12		d x 10		e x 4		f x 4
	g x 2		h x 2		i x 1		rx 2





<2>

	b x 4		c x 8
---	--------------	---	--------------





<3>

	c x 4
---	-------





<4>



	q x 4
---	-------





<5>




<6>





<7>

	b×2		c×4
---	------------	---	------------



<8>

 ox28




<9>





d×8



n×4



<10>



<11>

